



# SmartTouch Pro Controller

## Technical Data


### PRODUCT IMAGE



### ALTERNATE VIEWS



### REMOTELY CONTROL AIR CURTAINS



### FEATURES AND KEY PRODUCT INFORMATION

- ▶ Web server connectivity, the SmartTouch Pro integrates seamlessly with a building's Wi-Fi network, allowing remote access and control of the air curtain from any web browser enabled device connected to the network
- ▶ Complete Air Curtain control including fan speed, temperature, fan mode, heat and other functionality
- ▶ Capable of BACnet control and monitoring (*Optional add-on feature, not included as standard*)
- ▶ Temperature sensor for pinpoint readings that maximize air curtain effectiveness and active supplemental heat when programmed
- ▶ Lockable screen to prevent unwanted adjustments/tampering
- ▶ Unit mounting in slim, low profile case
- ▶ Remote mounting connection via a standard CAT-5e Ethernet cable and Wi-Fi Network access
- ▶ Back-lit LCD illuminates upon touch for easy/instant visibility regardless of ambient lighting

### APPLICATION NOTES

- CR2032-Reversed Polarity battery stores time settings in event of power failure
- Mirrored interface enables real-time adjustments to air curtain's operational functionality via computer, tablet, or smartphone-just as they would on physical controller.
- All screens (except home screen) feature back button to return to previous screen
- Remote mounting in standard, single gang electrical box
- Preset from factory to pair with air curtain and application requirements
- Screen indicators provide real-time operational status
- Screen can be set to display in English, Spanish or French

# SMARTTOUCH

QUESTIONS & TECHNICAL SUPPORT AVAILABLE. CONTACT US DIRECTLY:

Phone Support  
1-888-321-Aire (2473)


Email Support & Service  
CustomerService@PoweredAire.com

Sales Questions  
Sales@PoweredAire.com

# SmartTouch Pro Controller Technical Data

## SCREEN LAYOUT

### Main screen




### Lock screen (if activated)




If no lock screen, will go straight to **Main Control Screen**


### Menu Screen




### Fan Mode




### MAIN CONTROL SCREEN




### Dual Fan Speed




### Variable Fan Speed




### Heat Mode



### Temperature Set Point



### MENU SUB SCREENS



**SMARTTOUCH**

QUESTIONS & TECHNICAL SUPPORT AVAILABLE. CONTACT US DIRECTLY:


**Phone Support**  
1-888-321-Aire (2473)

**Email Support & Service**  
CustomerService@PoweredAire.com


**Sales Questions**  
Sales@PoweredAire.com

# SmartTouch Pro Controller Technical Data

## PRODUCT DRAWINGS



## WI-FI CONTROL SCREEN VIEW ON LAPTOP/TABLET MOBILE DEVICE



## Building Automation and Control Networks (BACnet)

There are 30 SmartTouch settings that can be controlled via BACnet ranging from SmartTouch setup to air curtain functionality (fan control, heat, temperature control) to key reminders (alarms, reminders and door counts). A complete list of these controls is available at [www.PoweredAire.com/ST](http://www.PoweredAire.com/ST). (Optional add-on feature, not included as standard)

### BACnet Alarms

Alarm Code (Decimal)	Message	Description
161	Motor contactor failure	Motor commanded on, no aux contact closure from contactor
162	Motor overload failure	Motor overload has tripped
163	Heat contactor failure	Heater commanded on, no aux contact closure from contactor
164	Heat overtemp failure	Overtemp switch has been activated
165	Flow switch 1 failure	Motor is commanded on, contactor is closed, no flow switch indication
166	Flow switch 2 failure	Motor is commanded on, contactor is closed, no flow switch indication

## Touchpad Performance

Hardware	
CPU	32-bit RISC CPU
Real Time Clock (RTC)	Yes
Communication Interface	
CN1	24VDC/CANbus to control board
CN2	Ethernet - BACnet IP, HTML Server (port 80)
WiFi Connection	Connect to router then use unit IP to access server
MMI (Man Machine Interface)	
LCD	4.3" (480W x 272H), 16.7M colors
Backlight Life	>30,000 hours
Brightness	650 nits
Touch Panel	Capacitive Touch
Electrical	
Power Input	24VDC (through RJ-45 port)
Power Consumption	2.5W @ 5VDC
Battery	CR2032-reverse polarity
Mechanical	
Dimensions (W x L x H)"	See drawings
Installation	Wall Mount or Air Curtain Mount
Ingress Protection	IP40
Environmental	
Operating Temperature	"-20°C~-+70°C (-4°F~-+158°F)"
Storage Temperature	"-30°C~-+85°C (-22°F~-+185°F)"
Ambient Relative Humidity	Temp < 60C 90%RH Max (96HRS Max) Temp > 60C Absolute humidity must be lower than humidity of 90%RH (96 HRS Max)

**SMARTTOUCH**

QUESTIONS & TECHNICAL SUPPORT AVAILABLE. CONTACT US DIRECTLY:

Phone Support  
1-888-321-Aire (2473)


Email Support & Service  
CustomerService@PoweredAire.com

Sales Questions  
Sales@PoweredAire.com


# SmartTouch Pro Controller Technical Data

## WI-FI/SERVER SETUP INSTRUCTIONS


### Step 1: Press the "MENU" button



### Step 2: Press the "Ethernet Settings" button



### Step 3: Select the "Static" option:




### Step 4: Assign Values (We recommend getting assistance from your IT admin)

Press on number fields to assign permanent values to the following, on both the Smart Touch Pro and your router:

- ▶ IP Address
- ▶ Subnet Mask
- ▶ Default Gateway
- ▶ MAC Address


Ensure that all values are set as static within your router to prevent conflicts with other devices on the network.

Ensure values set on Smart Touch Pro match settings on your router.



**Step 5:** Once values are assigned on both the router and Smart Touch Pro, press the "Reset System" button at the bottom of the touch screen. This will apply all modifications and automatically restart the Smart Touch Pro.

**Step 6.** Once restarted, return to the "Ethernet Settings" menu to confirm that all changes have been saved correctly. If not, repeat steps 4 and 5.




**Step 7:** To test connectivity to the Web server, ensure that you are using a computer on the same network. Open any web browser, enter the IP address that was assigned to the Smart Touch Pro, and press enter

At this point, the web server can be used exactly like the touch screen. Any changes made to the web server will be applied to the Smart Touch Pro in real time. As long as the Smart Touch Pro is on the same network, it can be controlled wirelessly from a cell phone, tablet, or laptop.

**To set up functionality for BACnet** - This is heavily dependent on the building management system (BMS) being used. The Smart Touch Pro is a BACnet over IP/Ethernet device but BACnet router can be used to interface with BACnet over MS/TP. (Optional add-on feature, not included as standard)

**The BACnet IP Port will be 47808.** Once set up, it will allow the Smart Touch Pro to be controlled through a BMS/BAS.



QUESTIONS & TECHNICAL SUPPORT AVAILABLE. CONTACT US DIRECTLY:

Phone Support  
1-888-321-Aire (2473)

Email Support & Service  
CustomerService@PoweredAire.com

Sales Questions  
Sales@PoweredAire.com